

Video Article

Profiling of Pre-micro RNAs and microRNAs using Quantitative Real-time PCR (qPCR) Arrays

Pauline Chugh*, Kristen Tamburro*, Dirk P Dittmer

Department of Microbiology and Immunology, Lineberger Comprehensive Cancer Center, Center for AIDS Research, University of North Carolina at Chapel Hill

*These authors contributed equally

Correspondence to: Dirk P Dittmer at ddittmer@med.unc.edu

URL: <http://www.jove.com/index/Details.stp?ID=2210>

DOI: 10.3791/2210

Citation: Chugh P., Tamburro K., Dittmer D.P. (2010). Profiling of Pre-micro RNAs and microRNAs using Quantitative Real-time PCR (qPCR) Arrays. JoVE. 46. <http://www.jove.com/index/Details.stp?ID=2210>, doi: 10.3791/2210

Abstract

Quantitative real-time PCR (QPCR) has emerged as an accurate and valuable tool in profiling gene expression levels. One of its many advantages is a lower detection limit compared to other methods of gene expression profiling while using smaller amounts of input for each assay. Automated qPCR setup has improved this field by allowing for greater reproducibility. Its convenient and rapid setup allows for high-throughput experiments, enabling the profiling of many different genes simultaneously in each experiment. This method along with internal plate controls also reduces experimental variables common to other techniques. We recently developed a qPCR assay for profiling of pre-microRNAs (pre-miRNAs) using a set of 186 primer pairs. MicroRNAs have emerged as a novel class of small, non-coding RNAs with the ability to regulate many mRNA targets at the post-transcriptional level. These small RNAs are first transcribed by RNA polymerase II as a primary miRNA (pri-miRNA) transcript, which is then cleaved into the precursor miRNA (pre-miRNA). Pre-miRNAs are exported to the cytoplasm where Dicer cleaves the hairpin loop to yield mature miRNAs. Increases in miRNA levels can be observed at both the precursor and mature miRNA levels and profiling of both of these forms can be useful. There are several commercially available assays for mature miRNAs; however, their high cost may deter researchers from this profiling technique. Here, we discuss a cost-effective, reliable, SYBR-based qPCR method of profiling pre-miRNAs. Changes in pre-miRNA levels often reflect mature miRNA changes and can be a useful indicator of mature miRNA expression. However, simultaneous profiling of both pre-miRNAs and mature miRNAs may be optimal as they can contribute nonredundant information and provide insight into microRNA processing. Furthermore, the technique described here can be expanded to encompass the profiling of other library sets for specific pathways or pathogens.

Protocol

The qPCR pre-miRNA profiling arrays can be set up as fully automated with a Tecan Freedom Evo robot (A) or by hand with the Matrix electronic multichannel pipette (B).

1) Prepare the master mix, primer plates and samples.

1. Primer plates containing 186 primer pairs in 96-well format (total of 2 plates) at 0.5pM should be stored at -80°C. Thaw plates out at room temperature, vortex and centrifuge briefly before use.
2. To prepare the master mix, thaw out SYBR Green 2x PCR Mix at room temperature. Each reaction uses 8ul master mix with 2ul primer. The composition of the master mix per reaction is 4ul SYBR mix, 3ul PCR grade water and 10-20 ng sample DNA or cDNA.
3. For setup of each 96-well primer plate, four master mix tubes will be needed. Samples can be run 4 samples per plate (singlicate), 2 samples per plate (duplicate) or a single sample in quadruplicate.
4. Prepare master mix by combining SYBR, water and sample in each of 4-2ml Eppendorf tubes. Each tube should contain enough master mix for approximately 100 reactions, allowing excess for pipetting waste. Vortex to mix.

A. Setup of pre-miRNA assay using the Freedom Tecan Evo robot.

1. Following initialization of the robot and loading of the Evoware program, flush three times with 30mls each to clear system of air bubbles that will interfere with pipetting accuracy.
2. Setup the robot platform to include the following:
 - Labeled 384-well plate
 - 96-well primer plate (1)
 - Master mixes
 - A trough containing 2% bleach
 - A filled system fluid container
 - Empty waste container
3. Begin automated robot run by selecting "Run" twice.
4. At end of program, remove 384-well plate and seal with LightCycler 480 sealing foil and centrifuge briefly. Place sealed 384-well plate in position 1 of the hotel.
5. Go to step 2.2 and repeat for primer plate 2 with new master mixes and a new 384-well plate.
 1. Place sealed plate in position 2 of the hotel.
6. Open new Evoware program for Loading the Lightcycler from the hotel and select "Run" twice.
 1. Freedom Evo will automatically load each plate into the LightCycler and run the following SYBR-green I/HRM cycling program: Pre (1 cycle):

50° for 5 minutes at ramp rate of 4.8°/sec
 95° for 5 minutes at ramp rate of 4.8°/sec
 Amp (45 cycles):
 95° for 15 sec at ramp rate of 4.8°/sec
 62° for 30 sec at ramp rate of 2.5°/sec
 (Single data acquisition during this step)
 Melting curve:
 95° for 5 sec at ramp rate of 4.8°/sec
 60° for 1 minute at ramp rate of 2.5°/sec
 95° continuous at ramp rate of .11°/sec
 with 5 acquisitions per °C
 Cool :
 50° for 30 sec at ramp rate of 25°/sec

B.Setup of pre-miRNA assay using the Matrix electronic multichannel pipette:

- Place contents of master mix tube 1 into a reservoir.
- Set the electronic pipette to aspirate 16ul of master mix with 2-8ul dispense steps followed by a purge step.
- For master mix 1, dispense 8ul into every other well of the 384-well plate (set on 384-well tip spacing), beginning with well A1. (i.e. wells A1, C1, E1, etc.) For the second 8ul dispense, move to column 3 (i.e. wells A3, C3, E3, etc.) then purge over a waste container and dispose tips.
- Follow this pattern for the remaining 5 cycles until you reach well A23.
- Repeat for master mix 2, (beginning with well A2, C2, E2, etc.); master mix 3 (beginning at well B1, D1, F1, etc.); master mix 4 (beginning at B2, D2, F2, etc.).
- For aliquotting of primer plate, set electronic pipette to aspirate 2ul and dispense 2ul with a purge step following. Dispense 2ul of primers from column 1 of 96-well primer plate (A-H) into the 384-well plate, wells A1, C1, E1, etc. Purge over a waste container and dispose tips. Repeat for wells A2, C2, E2; B1, D1, F1; and B2, D2, F2, etc.
- Repeat for rows 2-12 of 96-well primers, moving over every 2 columns for each primer column, until full 384-well plate has been aliquotted.
- Seal plates with a LightCycler sealing foil and centrifuge briefly.
- Place plates into a LightCycler 480 and cycle the plates according to the following settings using the SYBR Green I/HRM detection format:
 Pre (1 cycle):
 50° for 5 minutes at ramp rate of 4.8°/sec
 95° for 5 minutes at ramp rate of 4.8°/sec
 Amp (45 cycles):
 95° for 15 sec at ramp rate of 4.8°/sec
 62° for 30 sec at ramp rate of 2.5°/sec
 (Single data acquisition during this step)
 Melting curve:
 95° for 5 sec at ramp rate of 4.8°/sec
 60° for 1 minute at ramp rate of 2.5°/sec
 95° continuous at ramp rate of .11°/sec
 with 5 acquisitions per °C
 Cool :
 50° for 30 sec at ramp rate of 25°/sec
- Repeat using primer plate 2, aliquotting into a fresh 384-well plate using freshly prepared master mixes.

Secrets to success:

An important characteristic when designing PCR arrays is that all 186 primer pairs have the same annealing temperature, so the plate can be run at the same optimal PCR run program settings.

Each new array should be checked using three controls prior to running samples. These controls are:

1 run of all primers run with water or .1x TE to rule out primer contamination.

1 run of alternating water/TE and positive control, to ensure no carryover.

3 runs using the same positive control, to ensure reproducibility between runs.

Master mixes should be freshly prepared, and plates should be run within 24 hrs for optimal results

Primer plate foil should be removed slowly to reduce risk of contamination between wells.

When using a robot with fixed tips, 2% bleach wash is necessary to wash the tips between each pipetting step, followed by a water flush. This prevents and eliminates carryover, which could otherwise contaminate data and lead to inconclusive results.

After a plate is run through the Lightcycler, it should not be opened again in the PCR setup room. This helps prevent PCR contamination.

Representative Results:

qPCR results are typically represented by CT values as determined from the Lightcycler analysis software. A successful run usually consists of a range of CTs for samples, typically between 20-35 for samples that are positive. The water samples in a good run are always at a CT of >40 and any samples or specific wells with a CT over 37 are considered negative or not detected. As a general rule, samples yielding a CT of <10 are also unreliable and are excluded from further analysis. There are several ways to analyze qPCR data and the inclusion of internal controls in our assay helps control for variation of sample input. The pre-miR array includes a U6 control primer, which is often used as a reference gene to normalize CT values from different samples. This normalized value is referred to as the delta CT value (dCT). Results are often graphed as the raw CT, the dCT value or can be further analyzed to standardized values.

In Figure 1, analysis of the full pre-microRNA array of four different samples from a timecourse experiment is presented in heat map format. The relative expression of each pre-microRNA is shown and three major, distinct clusters emerged. The majority of pre-miRs analyzed underwent small, insignificant changes as expected (Figure 1A). However, a small portion of pre-microRNAs were significantly decreased (Figure 1B) or increased dramatically (Figure 1C) throughout the timecourse experiment. Levels of expression of each pre-microRNA were normalized to the 0h




Figure 2. Inclusion of internal controls in the qPCR-based pre-microRNA array. The raw CT values for 3 different genes and a no template control are shown. U6 is used as an internal positive control while PCR H2O serves as our negative control. Let-7a-1-1 is a microRNA normally expressed in many different cell types while KSHV LANA can be used as either a positive or negative control, based on viral status of the cell line or tissue used.




Figure 3. Melting peak analysis of pre-microRNA primers and lack of sample contamination. Melting curves were obtained using the Tm calling analysis in the LightCycler software. Two different primers (Primer A and B) for the same sample run in duplicate are shown. The melting temperature for each primer is distinct. However, the sample has only one peak, demonstrating the lack of sample contamination.

Disclosures

No conflicts of interest declared.

Discussion

QPCR is a highly sensitive assay that can be used to compare gene expression levels between samples in a study, as well as to determine positivity in the case of viruses. The benefit of using qPCR arrays is the ability to run many primers (in our case, 186 primer pairs) for each sample in a short period of time. Using a pipetting robot such as the Tecan Freedom Evo, the amount of time required to set an experiment up can be further reduced, and the accuracy and consistency of the robot can reduce and eliminate pipetting errors. Here we demonstrate how to use a Tecan Freedom Evo to set up a microRNA array, as well as an alternative method using a Matrix Electronic Multichannel Pipette, which can be implemented for labs who do not have access to a pipetting robot. qPCR arrays are also beneficial because all genes can be normalized to a single set of reference genes run on the same plate, reducing the cost and number of reactions.

As mentioned, there are several key features that are necessary when designing such an array. Since all samples on the PCR plate will be run at identical conditions, it is critical to design primers that function at the same temperatures and settings, or some primer pairs will fail. When designing primers, the sequences should always be checked by BLAST search to ensure that there is homology to your gene of interest and no other genes.

When running the array, it is critical that the environment is sterile and free of PCR contaminants that may result in false positives. If possible, PCR should be set up in a sterile work hood or a separate clean room, where PCR products are never used. Benches should be washed with Eliminate, water, and ethanol, and subjected to UV light for at least an hour after the run is complete.

The benefit of this technique is that this same strategy is applicable for any set of genes to be profiled by simply replacing the miRNA array with an array containing a different primer pair set. Our lab currently contains arrays for pre- miRNAs, KSHV, EBV, p53, and NFkB - all of which can be run in an identical method to those shown. The flexibility of this assay allows our lab to perform high-throughput gene profiling rapidly and reliably for any primer pairs that we wish to screen for.

Here, we described the array using cDNA from human cell lines to profile miRNA expression levels upon activation over a period of time. In addition to characterizing cell lines, the array can also be used to analyze clinical samples. Following RNA isolation, cDNA synthesis can be performed, and the cDNA can be run using this array to characterize gene expression. This can be useful in determining viral positivity, or gene expression profiles to further characterize which genes are upregulated in samples from infected patients. In summary, automated qPCR-based arrays are reproducible and reliable assays that allow for highly sensitive detection of a wide variety of genes from tissues and cell lines in a timely fashion.

Acknowledgements

This work was supported by NIH grants DE018304, R01DE018281. K.T. is supported by T32 GM07092-34 and by a grant to the University of North Carolina at Chapel Hill from Howard Hughes Medical Institute (HHMI) through the Med into Grad Initiative. PC is supported by T32 CA009156.

References

1. Bustin, A.A., *et al.* The MIQE Guidelines: Minimum Information for Publication of Quantitative Real-Time PCR Experiments. *Clinical Chem.* 55:4, 611-622 (2009).
2. Frégeau, C.J., *et al.* Automated Processing of Forensic Casework Samples using Robotic Workstations Equipped with Nondisposable Tips - Contamination Prevention. *J. Forensic Sci.* 53-3, 632-651 (May 2008).
3. O'hara, A.J. *et al.* Pre-micro RNA Signatures Delineate Stages of Endothelial Cell Transformation in Kaposi Sarcoma. *PLoS Pathog.* 5(4):e1000389 (Apr 2009).